

Application Chart - Front Control Arms

MODEL	UPPER		LOWER	
	FRONT PART#	REAR PART#	FRONT PART#	REAR PART#
1971-89 Impala*	PRP0005	PRP0012	PRP0021	PRP0009
1967-72 Chevelle/Monte Carlo	PRP0011	PRP0011	PRP0006	PRP0007
1973 Chevelle/Monte Carlo	PRP0012	PRP0012	PRP0006	PRP0009
1974 Chevelle/Monte Carlo	PRP0005	PRP0012	PRP0006	PRP0009
1975-77 Chevelle/Monte Carlo	PRP0005	PRP0012	PRP0021	PRP0009
1978-88 Chevelle/Monte Carlo*	PRP0014	PRP0014	PRP0010	PRP0007
1975-79 Nova	PRP0005	PRP0012	PRP0021	PRP0009
1973-74 Nova	PRP0011	PRP0011	PRP0007	PRP0007
1968-72 Nova	PRP0011	PRP0011	PRP0007	PRP0006
1967-69 Camaro	PRP0011	PRP0011	PRP0006	PRP0007
1970-72 Camaro	PRP0012	PRP0012	PRP0006	PRP0007
1973 Camaro	PRP0012	PRP0012	PRP0021	PRP0009
1974-79 Camaro	PRP0005	PRP0012	PRP0021	PRP0009
1980-81 Camaro	PRP0005	n/a	PRP0021	PRP0009

* Must drill frame for ½" bolts.