## **Hose loop installation instructions**

- 1. Using an 11/16" wrench, remove the hoses from ONE of the tee fittings on the lift. Use a 9/16" wrench to hold the tee and loosen the hoses slowly so oil doesn't spray out.
- 2. Replace the tee with the new one attached to the short hose.
- 3. Wrap the threads with teflon tape
- 4. Remove the quick disconnect fitting from the old tee and install it on the end of the short hose.

The lift can now be connected to the pump and used as normal. When storing the lift, connect the quick disconnect fittings on the lift together to prevent pressure buildup.

